

Unichip 4 Blackberry Guide

Download the Unichip Bluetooth for Blackberry application

1. Go to the browser on your Blackberry
2. Press the **Blackberry Menu** button / key and browse to the Go To option
3. In the web address bar type in:
<http://www.dastek.co.za/bbunichip/Unichip4BB.jad> (The correct capital letters must be used) Click the trackpad button
4. Select download and the phone will automatically install the program.

Initial Setup

1. The Unichip bluetooth module must be paired with the phone before initial use
 - a. Press the **Blackberry Menu** button / key and browse to Options
 - b. Scroll down and select **Bluetooth**
 - c. Press the Blackberry Menu button / key and select **Add Device**
 - d. Select **Search**
 - e. After successfully locating the Unichip device select the device to initiate pairing
 - f. When prompted for a passkey, enter **0000**
2. Set the device properties
 - a. Select the paired Unichip device and press the **Blackberry Menu** button / key and select **Device Properties**
 - b. Set **Trusted** to **Yes**
 - c. Set **Encryption** to **Disabled**
 - d. Press the **Blackberry Menu** button / key and select **Save**

Application Guide

1. Start the application. Typically this is done by pressing the **Blackberry Menu** button / key, selecting the **Downloads** icon and then selecting the **Unichip 4 BB** icon.
2. Once the application started, you can select the appropriate device by pressing the **Blackberry Menu** button / key and selecting the required device
3. Once connected the screen will display the connected device and the currently selected map
4. To change the map, press the **Blackberry Menu** button / key and selecting it from the menu. The screen will update if the map was successfully changed
5. To close the application, press the **Blackberry Menu** button / key and select either **Close Serial Port** or **Close**